USER MANUAL – EN

IN 32275 Tower for Pilates reformer inSPORTline Oquiler



Images are illustrative, final design and finish are subject of change.

CONTENTS

SAFETY INSTRUCTIONS 3
ASSEMBLY 4
MAINTENANCE 6
ENVIRONMENT PROTECTION 6
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS 7

SevenSport s.r.o. reserves the right to make any changes and improvements to its product without prior notice. Visit our website www.insportline.eu where you will find the latest version of the manual.

SAFETY INSTRUCTIONS

- Read the manual before use and save it for future reference.
- Keep out of reach of children and pets.
- For one person only at a time.
- If you feel nausea, chest pain or any other abnormal physical symptoms, stop using the device immediately.
- Keep limbs away from moving parts. Be careful when adjusting the springs.
- Place the machine on a flat, firm and clean surface.
- Always wear suitable sports clothing and footwear, do not wear loose clothing or jewelry.
- Use the machine only for the purpose for which it was designed.
- Do not make unauthorized modifications.
- Remove all sharp objects around the machine during use.
- The machine must be placed at least 0.6 m from other objects.
- People with limited mental or physical abilities must not use the machine.
- Always warm up your muscles with a warm-up exercise before training.
- If sharp edges appear on the machine, stop using the machine immediately.
- Do not place sharp objects on the device. No adjustable part should protrude so as to impede the user's movement.
- Before each use of the machine, check that all joints are properly secured.
- Category: S for commercial use
- Weight limit: 100 kg
- WARNING: Consult a physician before beginning any exercise program. A physician's opinion is especially important if you have a medical condition. The seller assumes no responsibility for any injuries or property damage resulting from the use of the device.
- **WARNING:** This tower is intended exclusively for use with the product **IN 32273 Pilates reformer inSPORTline Oquiler.** Before use, ensure that the tower is properly assembled and secured according to the instructions in the manual. Use with incompatible equipment, incorrect installation, or improper use may lead to instability, product damage, and/or user injury. Always observe the maximum allowed load and safety instructions listed on the product label and in this manual.

ASSEMBLY

Prepare the tower bracket. Use the screws to connect the tower frame bracket and the L-shaped bracket.





Align the holes of the reformer frame and the bracket.



Fasten the bracket to the reformer frame using 4x bolts on the outside and 4x bolts on the inside.





Slide the tower frame into the bracket and secure it using 3x bolts.



Take out the raised part as shown in the picture, unscrew the two screws at the top, insert them into the accessory hole shown in Figure 2, and slide it into the tube bracket on the frame.



Remove the U-shaped frame, place it in the position shown in the picture, and insert the locking pin.



WARNING

Before starting any exercise, make sure that the footrest support bar is fully engaged in both positioning slots (on both the left and right sides). Otherwise, serious injury may occur.

MAINTENANCE

- When assembling, tighten all screws properly and adjust the device to a horizontal position.
- Wipe off sweat after exercise. Clean the device with a cloth and mild detergents. Do not use solvents or aggressive detergents on plastic parts.
- Place the product in a clean, ventilated and dry room.
- Do not expose the device to direct sunlight.

ENVIRONMENT PROTECTION

After the product lifespan expires or if the possible repairing is uneconomical, dispose of it according to the local laws and is environmentally friendly in the nearest scrapyard.

By proper disposal you will protect the environment and natural resources. Moreover, you can help protect human health. If you are not sure of the correct disposing, ask local authorities to avoid law violations or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Kutnohorská 531, Štěrboholy Retail Park, 109 00, Prague 10, ČR, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations, it depends whether the Buyer is the End Customer or not.

"The Buyer who is the End Customer" or simply the "End Customer" is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

"The Buyer who is not the End Customer" is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

Batteries

6-month battery warranty – we guarantee that battery's nominal capacity does not fall below 70% of its total capacity within 6 months of the product's sale.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damage
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

CZSEVEN SPORT s.r.o.

Registered Office: Kutnohorská 531, Štěrboholy Retail Park, 109 00, Prague 10, Czech RepublichEadquaters: Dělnická 957, Vítkov, 749 01Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264VAT ID:CZ26847264

Phone: +420 556 300 970E-mail: eshop@insportline.cz reklamace@insportline.cz servis@insportline.cz

Web: www.inSPORTline.cz

SKStores inSPORTline SK, s.r.o.

Headquaters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 46259317VAT ID:SK2023299729

Phone: +421(0) 917 700 098E-mail: objednavky@insportline.sk reklamacie@insportline.sk servis@insportline.sk

Web: www.inSPORTline.sk

About shipping

