




**USER MANUAL – EN**

**IN 19988 Air Exercise bike inSPORTline Airbike Pro**



# CONTENTS

- SAFETY INSTRUCTIONS..... 3
- ASSEMBLY ..... 5
- SET UP..... 10
- CONSOLE ..... 13
  - PROGRAMS ..... 16
- BATTERY REPLACEMENT ..... 20
- USE ..... 20
- EXERCISING INSTRUCTIONS ..... 21
- CORRECT BODY POSTURE ..... 21
- MAINTENANCE ..... 22
- STORAGE ..... 22
- IMPORTANT NOTICE ..... 22
- ENVIRONMENT PROTECTION ..... 22
- DIAGRAM..... 23
- PARTS LIST ..... 24
- TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS..... 25

## SAFETY INSTRUCTIONS







- Read all instruction in this manual before using this equipment and keep it for future references.
- Use the machine only for its intended use as described in this manual.
- Inspect and tighten all the loose parts before this equipment is used.
- Keeps hands away from moving parts.
- Keep children and pets away from the machine at all time. DO NOT leave children unattended in the same room with the machine.
- Before using the machine to exercise, always do stretching exercise to properly warm up.
- Inspect the machine before each use; make sure all of the connections are tightly secured.
- Only one person at a time should use the machine.
- If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms, STOP the workout at once. CONSULT A PHYSICIAN IMMEDIATELY.
- Position the machine on a clear, levelled surface. DO NOT use the machine near water or outdoor.
- Always wear appropriate workout clothing when exercising. DO NOT wear robes or other clothing that could become caught in the machine. Sporting shoes are recommended when using the machine.
- Do not place any sharp object around the machine.
- Disabled persons should not use the machine without a qualified person or physician in attendance.
- Never operate the machine if the machine is not functioning properly.
- Only carry out training work on the equipment when it is in perfect working order. Only use original spare parts in the event of a repair.
- Do not use strong solvents for cleaning, and only use the tools supplied, or suitable ones of your own, for any repairs that may be required.
- Please dispose of the packaging and any parts that have to be replaced subsequently (all parts for the unit) at suitable collecting points or containers with a view to saving the environment.
- DO NOT pull out the seat tube over the warning line" max" which showing on the tube, when you adjust the height of the seat.
- Not for therapeutic use.
- For safety keep at least 0.6 m free space around the device.
- Do not put sharp items on the device. Adjustable parts should not interfere with user's movement.
- **Category:** SC (EN ISO 20957-1: 2013, EN ISO 20957-5: 2016) for professional and commercial use
- **Weight limit:** 160 kg
- **WARNING!** The heart rate frequency monitoring may not be completely accurate. Overexertion during training can lead to a serious injury or even death. If you start to feel faint, stop the exercise immediately
- **WARNING:** Before beginning any exercise program, consult your physician. This is especially important for persons with pre-existing health problems. The seller assumes no responsibility for personal injury or property damage sustained by or through the use of this product.

## PRODUCT DESCRIPTION








	17	1. Left handlebar	
		18	2. Footrest
		19	3. Left pedal
		20	4. Seat
			5. Seat post
			6. Adjustment lever
			7. Left cover
			8. Lever
			9. Serial number
			10. Leveling foot
			11. Rear stabilizer
			12. Warning label
			13. Right pedal
			14. Right crank
			15. Right cover
			16. Connection rod
			17. Bottle holder
			18. Console holder
			19. Console
			20. Right handlebar
			21. Fat cover
			22. Footrest
			23. Main frame
			24. Transport wheel
			25. Front stabilizer

## ASSEMBLY

The packed includes:

	Custom wrench		Allen key 4 mm
	Wrench 14/17 mm		Allen key 5 mm
	Screwdriver		Allen key 6 mm

Assembly material:

Pic	No.	Name	Qty.
	93	Nylon nut M8 x 1,25	2
	105	Bolt M8 x 1,25 x 30 mm	4
	106	Bolt M5 x 0,8 x 12 mm	4
	107	Bolt M6 x 1 x 15 mm	6
	108	Bolt M10 x 1,5 x 20 mm	8
	109	Bolt M6 x 1 x 10 mm	2
	112	Arc washer M10	8

Place all parts out of the box on a clean surface. Remove all packing material and place it in the box. Do not remove the packing material until the exercise bike is assembled. Follow carefully each step.

Some parts are tested and can carry test marks. Marks on color may be noticeable, but it is not an indicator of damage.


Some parts may be connected for transport purposes, follow the instructions and, if necessary, disconnect them and then reconnect.

## STEP 1

Remove the screws from the cardboard rollers from the front of the main frame (1). Make sure that the transport wheels (43) on the front stabilizer (40) face forward. Attach the front stabilizer (40) to the main frame (1) with screws (108) and washer (112).

## STEP 2

Remove the screws from the cardboard rollers from the back of the main frame (1). Attach the rear stabilizer (44) to the main frame (1) with screws (108) and washer (112).



### STEP 3

Attach the right handlebar (58) to the main frame holder (1) and attach the footrest (83) to the main frame holder. Refer to the picture below. Attach the footrest using the modified spanner (83). Attach the cap (84) to the footrest (83).


### STEP 4

Attach the right connection rod (29) to the bottom of the right handle (58) using the mounting plate (74), spacer (75), bolt (105) and nut (93). Do not tighten the screw until step 5.

### STEP 5

Attach the mounting plate (74) to the right connecting rod (29) with the screws (107). Now tighten all screws.

Repeat steps 3 to 5 for the left handlebar (51) and the left connecting rod (26).



## STEP 6


**NOTE:** The right pedal is marked R. The left pedal is marked L. The right pedal is screwed clockwise. The left pedal is screwed counterclockwise.

Loosen the screw (109) on the right crank (28). Screw the right pedal (39) onto the right crank (28) as shown. Tighten the pedal. The pedal shoulder (38, 39) should touch the crank. To secure, screw the screw (109) onto the right (28) and left (38) crank

## STEP 7

Attach the sensor cable (59) to the connecting cable (63) and attach the console bracket (48) to the main frame (1) with the screw (105).

Do not damage the cables while attaching the console bracket (48).






### STEP 8

Insert two AA batteries into the console (85). Batteries are not included. Connect the connecting cable (63) to the console (85). Secure the console (85) in the console bracket (48) with the screw (106).

Do not damage the cables while attaching the bracket (85).

### STEP 9

Attach the bottle holder (113) to the console bracket (48). Place the bottle (114) in the bottle holder (113). Attach the bottle holder (113) to the console bracket (48). Place the bottle (114) in the bottle holder (113).




## SET UP

Place the exercise bike in place of use. We recommend placing the exercise bike on a protection mat. We recommend a free space of at least 122 cm wide and 183 cm long.

**Leveling:** Align the exercise bike with the leveling feet (46) located on the rear stabilizer (44).

**Transportation:** There are transport wheels (43) on the front stabilizer (40). Place the exercise bike on the front wheels (43) using the handrails.



Visually inspect the bicycle. Slowly turn the pedal cranks to check the functionality.

**WARNING:** Make yourself and other users familiar with the safety labels placed on the exercise bike.

## CAUTION

Before assembling or using this product, read and follow the Manual, warnings, and instructions that accompany this product. Failure to follow all warnings and instructions could result in injury or property damage.

Keep others including children & pets away from equipment when in use.

Consult your physician before starting this or any exercise program. This is especially important if you are over the age of 35 or have any pre-existing health condition. Always make sure all screws are securely tightened before the workout.

The Max. User Weight is 160 kgs/352 lbs.

### WARNING

Before assembling and using the exercise bike, carefully read the manual, warnings, cautions and instructions associated with this product. Any failure to do so may result in injury or property damage.

Keep children and pets away from the product.

Ask your doctor for advice before starting the exercise program, especially if you are over 35 or have health problems.

Make sure that all screws are properly tightened before use.


**Maximum load capacity:** 160 kg

### SEAT HEIGHT ADJUSTMENT

For effective exercise it is important to set the correct saddle height. Your foot should be slightly bent and relaxed when you step down.

If the foot is too stretched or user can't reach the pedal, the seat must be lowered. If the legs are too bent, the seat must be raised. Loosen the hand screw (76) and move the seat post (60). Adjust the seat height (73) and secure with the hand screw (76).


Tighten the hand screw (76) properly before use.



## SEAT POSITION

You can move the seat (73) forward or backward. By adjusting the seat, you exercise the different muscles.


Lift the lever (62) and adjust the seat (73) to the desired position. Then release the lever (62) and lock the seat (73) in the desired position).



## HEART RATE

The exercise bike does not include a chest belt or other forms of heart rate transmission. However, it is compatible with chest belts operating at 5 kHz.


The chest belt sends information to the console (85). In this way, you practice most effectively because you have the required heart rate information for maximum training efficiency.



Follow the instructions attached to the purchased chest strap for pairing.

## CONSOLE

The exercise bike uses a fan system to create resistance. The console helps you create goals and track progress.




**TURN ON:** Press the pedal or press any button.

**TURN OFF:** In standby mode, the console will turn off after 60 seconds of inactivity. During training, except for **Interval Program**, the console will turn off automatically after 90 seconds of inactivity. During the **Interval Program**, the program is stopped with the STOP button, otherwise the program will run to completion. It then turns off automatically after 90 seconds.

## BUTTONS

ENTER	Confirm the entered value or program selection
START	Starting the program or turning on the STOP program
STOP	Press to stop / pause the program Press and hold for 2 seconds to restart console and setting up age
▲ UP	Increase value
▼ DOWN	Decrease of value
TARGET TIME	Set the desired training time
TARGET DISTANCE	Set the desired training distance
TARGET CALORIES	Set the desired calories burned
TARGET HEART-RATE	Target heart rate You must have a chest strap attached for use
INTERVAL 10/20	Enter Interval 10/20 program
INTERVAL 20/10	Enter Interval 20/10 program
INTERVAL CUSTOM	Enter the Interval custom program and set your own training interval

## DISPLAY

	<b>TIME</b>	<p>Shows training time from 1 sec to 1:59:59.</p> <p>0:00 flashes to set the target time from 1 sec to 1:59:00 and counts down from that value.</p>
	<b>DISTANCE</b>	<p>Displays a distance of 0.1 miles to 999.9 miles.</p> <p>0: 0 flashes to set the target distance from 0.5 to 999.5 miles and starts counting down from that value.</p>
	<b>CALORIES</b>	<p>Displays calories burning to 999 Kcal.</p> <p>Calories are for reference only and are not intended for medical purposes.</p> <p>0 flashes to set target calories from 10 to 990 Kcal and starts counting down from that value.</p>
	<b>RPM</b>	<p>Displays revolutions per minute from 0 to 199.</p>
	<b>SPEED</b>	<p>Displays the current speed from 0 to 99.9 mph.</p>
	<b>WATTS</b>	<p>Displays power from 0 to 1999 watts.</p>
	<b>HEART RATE</b>	<p>Shows heart rate from 40 to 220 beats per minute. You must have a chest strap attached to see the value.</p> <p>The heart rate monitoring system is for guidance only and does not serve medical purposes.</p>

## PROGRAMS

The console includes programs: **Normal Program, Time, Distance, Calories, Heart-Rate, 10/20 Interval, 20/10 Interval, Custom Setting program.**

### NORMAL PROGRAM


	<p>Step on to turn on the console. The display will show a flashing 30 for age settings from 1 to 99. With ▲/▼ adjust the value and confirm with ENTER. Console will enter standby mode. Press START, or start paddeling to start the program. All values will start to count up. Press STOP to turn off the program. Console will enter standby mode after 30 seconds of inactivity. Console will turn off after 60 seconds of inactivity.</p> <p>In standby mode the LCD display shows: Interval 10/20, Interval 20/10, Interval custom, Ready, Work, Rest, Time, Distance, Calories, Watts, Speed, RPM and Heart rate in a sequence every second</p>
<p><i>You must wear the <b>HEART RATE TRANSMITTER</b> around your chest to measure your heart rate. Otherwise, it will show a "P" in the heart rate window for no signal.</i></p>	

### TIME PROGRAM


<p>This program is running.</p> <p>Counts down from the preset value.</p>	<p>Press <b>Target Time</b> display shows flashing 0:00 for adjusting the time value from 1:00 minute to 1:59:00 hours. With ▲/▼ adjust the value and confirm with ENTER. Program will start. During exercise, the set value will count down, the other values will be counted up. When the set value is met, the console will stop for 30 seconds and then automatically shut down after 60 seconds of inactivity.</p>
---	---



## DISTANCE PROGRAM

<p>This program is running.</p>  <p>Counts down from the preset value.</p>	<p>Press <b>Target Distance</b> display shows flashing 0:0 for adjusting the distance value from 0,5 mile to 999,5 miles. With ▲/▼ adjust the value and confirm with ENTER. Program will start. During exercise, the set value will count down, the other values will be counted up. When the set value is met, the console will stop for 30 seconds and then automatically shut down after 60 seconds of inactivity.</p>
---	---


## KALORIES PROGRAM

<p>This program is running.</p>  <p>Counts down from the preset value.</p>	<p>Press <b>Target Calories</b> display shows flashing 0 pro for adjusting the distance value from 10 to 990 Kcal. With ▲/▼ adjust the value and confirm with ENTER. Program will start. During exercise, the set value will count down, the other values will be counted up. When the set value is met, the console will stop for 30 seconds and then automatically shut down after 60 seconds of inactivity.</p>
---	--

## HEART RATE PROGRAM

The heart rate program is a preset program. The program monitors your pulse, using the sound signal and arrows to indicate if the pulse is outside the set threshold (65% or 85% of the maximum heart rate). You must enter your age and have a chest strap with signal transmission.

Press the Target heart-rate button, the LCD display will flash 30, then set the age from 1 to 99. Use to set the value and confirm with ENTER. The program starts. The console starts to calculate values for 65% and 85% of the maximum heart rate value based on the specified age. The heart rate value will be displayed during exercise and all other data will be added. Press STOP to stop the program.



If the value falls below 65%, the up arrow and the preset value begin to flash. A sound signal will sound every 10 seconds until the user reaches 65% and higher.

If the value exceeds 85%, the down arrow and the preset value begin to flash. sound signal will sound every 10 seconds until the user reaches 85% and below.

If the value remains between 65% and 85%, only the current heart rate will flash.

Calculation for heart rate for 30 years old:

- Maximum heart rate:  $220 - 30 \text{ (age)} = 190$
- 65 %:  $190 \text{ (Maximum heart rate)} \times 0,65 = 123$
- 85 %:  $190 \text{ (Maximum heart rate)} \times 0,85 = 161$

The program will check that you to stay between 65% and 85%.


**INTERVAL 10/20**

<p><b>This program is running.</b></p> <p><b>Cycles you have done.</b></p> <p>Switch to display the work time and rest time.</p> <p>Program preset 8 cycles</p> <p>Counts down from 3:40.</p>	<p>A program where the user exercises for 10 seconds and then rest for 20 seconds..</p> <p>Press the 10/20 Interval button to start the program. Time starts to count down from 3:40 minutes (10 sec x 8 reps, 20 sec x 7 reps). Other functions are added.</p> <p>You can only stop the program by pressing the STOP button. When the program is complete, the program stops for 30 seconds and then turns off after 60 seconds of inactivity.</p>
---	---

**INTERVAL 20/10**

<p><b>Cycles you have done.</b></p> <p><b>This program is running.</b></p> <p>Switch to display the work time and rest time.</p> <p>Program preset 8 cycles</p> <p>Counts down from 3:50.</p>	<p>A program where the user exercises for 20 seconds and then rest for 10 seconds.</p> <p>Press the 20/10 Interval button to start the program. Time starts to count down from 3:50 minutes (20 sec x 8 reps training, 10 sec x 7 reps rest). Other functions are added.</p> <p>You can only stop the program by pressing the STOP button. When the program is complete, the program stops for 30 seconds and then turns off after 60 seconds of inactivity.</p>
---	--

## CUSTOM INTERVAL PROGRAM

<p style="text-align: center;"><b>This program is running.</b></p>  <p>② Enter the work time. ③ Enter the rest time.</p> <p>① Enter the desired cycles.</p>	<p>The user can set their own training interval from 1 second to 9:59 minutes and the number of cycles from 1 to 99.</p> <p>Press <b>Custom interval</b>, 00/01 starts flashing, for setting up the number of repetitions 1 - 99. Use the arrows to set the value and confirm with ENTER. Then set the training and rest time from 1 second to 9:59 minutes. Confirm with ENTER. The time will count down from the set value, the other values will be counted up. The program is only turned off by pressing the STOP button or when the set time has finished. The program then stops for 30 seconds and then turns off automatically after 60 seconds of inactivity.</p>
--	---

## FUNCTION DESCRIPTION

- Press STOP to turn off the program.
- When the program is running, the console will enter standby mode after 30 seconds of inactivity. The console will shut down after another 60 seconds of inactivity.
- To pause a running program, press START. A beep sounds every 30 seconds and all values are shown on the display every 2 seconds. Press START again to start the program. The console enters standby mode after 5 minutes of inactivity. The console will shut down after an additional 30 seconds of inactivity.
- Press and hold the STOP button for 2 seconds to restart the console and start a new program.
- Distance can be displayed in kilometers or miles. Press START and ENTER simultaneously. KM or M is displayed. Use the arrows to select KM or Mile and press ENTER to confirm.


## BATTERY REPLACEMENT

Open the rear cover on the console (85)

The console is powered by 2 AA batteries (1.5V). Batteries are not included.

### Note:

- Do not mix old and new batteries.
- Use the same type of battery.



## USE

Exercise on the exercise bike is based on very simple movements, but you will surely fall in love with them. Thanks to simplicity of the exercise on the exercise bike in can be done by elderly people. Prior to exercise, it is necessary to adjust the height of the saddle. It is important that you sit comfortably. The bicycle saddle must be set so that you can hold the ergonomically shaped handles when sitting. You should not have fully extended hands. You can damage your muscles.

To ensure a comfortable and comfortable exercise, put your feet on the pedal. Nowadays, all modern pedals are equipped with straps for fastening and stabilizing of the foot. It is important for your foot to be firmly and safely positioned during exercise.

The basis of exercising on a bicycle is that the legs are moving on a specific elliptical path. This movement is very similar to cycling. When doing exercise on a bicycle, you just sit on the saddle with the right height, keep your feet firmly in the pedals, hold the ergonomically shaped handles and exercise.

It is advisable at the beginning to choose a lower load. If you exercise at regular intervals on an exercise bike, you can gradually increase the load. You can increase the load gradually over a week or two weeks. Selecting a high load during the start of training can lead to rapid fatigue and muscle damage.

When exercising, it's important to choose the right load and the right tempo. Try to keep it throughout the exercise. It is not recommended to choose a high pace right from the start. Increase tempo after about a week of regular exercise. The high pace is not equal to the faster burning of calories. Correct calorie burning is reflected in an appropriate and regular exercise. At the beginning of the exercise, the number of burned calories may seem low, but regular and appropriate exercise is the key to achieving the best results.

Exercise on the exercise bike also leads to the formation of muscles. It is mainly used to strengthen the thigh and calf muscles. While exercising on a bicycle, you also move your buttocks.

If you want to exercise right, you should not forget to breathe properly. Proper and regular breathing is recommended in any exercise. It is important to keep regular deep inhales and exhales. Regular and proper breathing during exercises on the exercise bike involves intense exercise of the abdominal muscles. It is advisable to practice 30-35 after consuming food. Failure to do so may result in less calories burned, and in older age even lead to digestive problems.

For best results, you should also consider your diet. It is recommended to start a day of eating sweet food and pastries or muesli with milk. For lunch is recommended to eat a caloric richer meal. Do not forget about the soup. In the evening, light meals are recommended. If you want to improve your health, it's not just a regular exercise but a whole diet.

Bicycle exercise is an effective exercise for all busy people. Exercise on the exercise bike is effective in strengthening muscles, especially thighs, calves and buttocks. Regular exercise can lead to a slimmer figure. Exercise is recommended not only as a winter training for cyclists but also for people who want to burn excess calories. Regular breathing, regular exercise, reasonable tempo, and balanced diet can lead to your desired results.

## EXERCISING INSTRUCTIONS

A successful workout begins with warm-up exercises and ends with cool-down (relaxing) exercises. The warm-up exercises should make your body ready for the main workout. The cool-down phase should protect your muscles from injuries and cramps. Do warm-up and cool-down exercises as shown in the chart below.



### Touching your toes

Slowly bend your back from hips. Keep your back and arms relaxed while stretching downwards to your toes. Do it as far as you are able and hold the position for 15 seconds. Bend your knees slightly.



### Upper thigh

Lean against a wall with one hand. Reach down and behind you. Lift up your right or left foot to your buttock as high as possible. Keep for 30 seconds and repeat twice for each leg.



### Hamstring stretched

Sit and outstretch your right leg. Rest the sole of your left foot against the inside of your right thigh. Stretch out your right arm along your right leg as far as you can. Hold for 15 seconds and relax. Repeat all with your left leg and left arm.



### Inside upper thigh

Sit on the floor and place your feet together. Knees are pointed outwards. Pull your feet as close as possible to your groin. Press your knees carefully downwards. Keep this position for 30-40 seconds if possible.



### Calves and Achilles tendon

Lean against a wall with your left leg in front of the right one and your arms forward. Stretch out your right leg and keep your left foot on the floor. Bend your left leg and lean forwards by moving your right hip in the direction of the wall. Hold for 30-40 seconds. Keep your leg stretched and repeat exercising with other leg.

## CORRECT BODY POSTURE

When training, keep your body upright, or you can learn your hand on your forearms. During pedaling, you should not have your legs fully extended. Your knees should be slightly bent when fully pressing

down the pedal. Keep your head straight with your spine to minimize the pain of the cervical muscles and upper back muscles. Always exercise fluently and rhythmically.

## **MAINTENANCE**

- When assembling, tighten all screws and adjust the bike to the horizontal position.
- Check the screws after 10 hours of use.
- Wipe the sweat after the exercise. Clean the device with a cloth and gentle cleanser. Do not use solvents or aggressive cleaners on the plastic parts.
- When noise is increased, it is necessary to check that all joints are tightened properly.
- Place the product in a clean, ventilated and dry room.
- Do not expose the device to direct sunlight.

## **STORAGE**

Keep the exercise bike in a clean and dry environment. Make sure the power switch is turned off and the exercise bike is not plugged into the power socket.

## **IMPORTANT NOTICE**

- This exercise bike comes with standard safety regulations and is only suitable for professional and commercial use. Any other use is prohibited and may be dangerous to users. We are not responsible for any injury caused by improper and forbidden use of the machine.
- Consult your doctor before starting training on the exercise bike. Your doctor should evaluate whether you are physically fit to use the machine and how much effort you are able to undergo. Incorrect exercise or switching of the body can harm your health.
- Carefully read the following tips and exercises. If you experience pain, nausea, breathing, or other health problems during exercise, immediately stop the exercise. If the pain persists, contact your doctor immediately.
- This exercise bike is not suitable for medical purpose. It can also not be used for healing purposes.
- The heart rate monitor is not a medical device. It provides only approximate information about your average heart rate, and any suggested pulse rate is not medically binding. Accumulated data may not always be accurate regarding uncontrollable human and environmental factors.


## **ENVIRONMENT PROTECTION**

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyards.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

# DIAGRAM



## PARTS LIST

No.	Name	Qty.	No.	Name	Qty.
1	Main Frame	1	36	Seat Post Hollow Cap	1
2	Fan Hub	1	37	V-Ribbed Belt (690-J6)	1
3	Fan	1	38	Left Pedal	1
4	Fan Hub Spacer	1	39	Right Pedal	1
5	Fan Hub Sleeve	1	40	Front Stabilizer	1
6	Fan Shaft	1	41	Endcap (Ø90 mm)	2
7	Bearing (6301Z)	1	42	Square Foot Pad	2
8	Bearing (6901Z)	3	43	Moving Wheel	2
9	Left Fan Cage	1	44	Rear Stabilizer	1
10	Right Fan Cage	1	45	Adjustment Lock	2
11	Plastic Strip	1	46	Stand	2
12	Strip Holder	2	47	Endcap (Ø101.6 mm)	2
13	Tension Bracket	2	48	Computer Support	1
14	Eyelet Bolt (M8 x 1.25 x 45mm)	2	49	Round Plug (Ø25 mm)	2
15	Nut (M8 x 1.25)	2	50	Grommet Plug	2
16	Crank Shaft	1	51	Left Handlebar	1
17	Pulley	1	52	Sensor Clip	1
18	Right Crank	1	53	Bearing (6003Z)	2
19	C Ring (S25)	1	54	Bearing (6202Z)	2
20	Spring Pin	1	55	Bearing (6203Z)	2
21	Bearing (6005)	2	56	C Ring (S40 mm)	2
22	Bearing Nut	1	57	Round Plug (Ø38 mm)	2
23	Left Crank	1	58	Right Handlebar	1
24	Left Disc Crank	1	59	Sensor Wire	1
25	Bearing (2205ZZ)	2	60	Seat Post	1
26	Left Linkage	1	61	Sliding Post	1
27	C Ring (S52)	4	62	Adjustment Lever	1
28	Right Disc Crank	1	63	Connection Wire	1
29	Right Linkage	1	64	Pivot Axis	1
30	Left Cover	1	65	Long Spring	1
31	Right Cover	1	66	Set Block	1
32	Crank Cover	2	67	Short Spring	1
33	Small Crank Cover	2	68	Bushing (Ø8 x Ø12 x 7mm)	1
34	Left Fan Cage Cover	1	69	Linkage Rod	1
35	Right Fan Cage Cover	1	70	Ball (Ø10 mm)	1



71	Square Plug	1	98	Nut M6 x 1	1
72	Seat Holder	1	99	Bolt M6 x 1 x 35 mm	1
73	Seat	1	100	Bolt ST4 x 15 mm	12
74	Fixing Plate	2	101	Bolt M4 x 0.7 x 10 mm	4
75	Disc Spacer	2	102	Bolt M8 x 1.25 x 40 mm	2
76	Cam Handle	1	103	Nut M8 x 1.25	3
77	Handle Spacer	2	104	Bolt M5 x 0.8 x 8 mm	4
78	Handle Sleeve (Ø8.2 x Ø10 x 43.2mm)	1	105	Bolt M8 x 1.25 x 30 mm	4
79	Gasket	1	106	Bolt M5 x 0.8 x 12 mm	4
80	Pressure Plate	2	107	Bolt M6 x 1 x 15 mm	6
81	Compression Block	1	108	Bolt M10 x 1.5 x 20 mm	8
82	Reset Spring	1	109	Bolt M6 x 1 x 10 mm	2
83	Footrest	2	110	Bolt M8 x 1.25 x 50 mm	1
84	Decorative Plug	2	111	Washer M8	1
85	Computer	1	112	Washer M10	8
86	Magnet	1	113	Water bottle holder	1
87	Bolt M8 x 1.25 x 20 mm	1	114	Water bottle	1
88	Bolt M5 x 0.8 x 12 mm	8	115	Caution label	1
89	Nut M12 x 1.25	4	116	Serial number	1
90	Bolt M6 x 1 x 12 mm	6	117	Allen key 4 mm	1
91	Bolt M10 x 1.5 x 40 mm	4	118	Allen key 5 mm	1
92	Bolt M6 x 1 x 20 mm	1	119	Allen key 6 mm	1
93	Nut M8 x 1.25	5	120	Allen key 14/17 mm	1
94	Washer M8	3	121	Wrench	1
95	Bolt M6 x 1 x 16 mm	1	122	Screwdriver	1
96	Bolt ST4 x 10 mm	7	123	Manual	1
97	Bolt M6 x 1 x 15 mm	2			

## TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

### General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

### **Warranty Conditions**

#### **Warranty Period**

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

#### **The Warranty does not cover defects resulting from (if applicable):**

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

### **Warranty Claim Procedure**

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the

Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

**CZ**

**SEVEN SPORT s.r.o.**

Registered Office: Strakonická 1151/2c, Praha 5, 150 00, ČR  
Headquarters: Dělnická 957, Vítkov, 749 01  
Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264  
VAT ID: CZ26847264

Phone: +420 556 300 970  
E-mail: eshop@insportline.cz  
reklamace@insportline.cz  
servis@insportline.cz

Web: www.inSPORTline.cz

**SK**

**inSPORTline s.r.o.**

Headquarters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 36311723  
VAT ID: SK2020177082

Phone: +421(0)326 526 701  
E-mail: objednavky@insportline.cz  
reklamacie@insportline.cz  
servis@insportline.cz

Web: www.inSPORTline.sk