




USER MANUAL – EN

IN 25951 Indoor Bike inSPORTline CycleAir



CONTENTS

- SAFETY INSTRUCTIONS..... 3
- PRODUCT DESCRIPTION 4
- FASTENERS 5
- ASSEMBLY 6
- CONTROL PANEL 11
 - INTRODUCTION 11
 - FUNCTION..... 11
 - DISPLAY 12
 - PROGRAMS 14
 - BLUETOOTH 16
- RESISTANCE ADJUSTMENT 17
- HANDLES AND SEAT POSITIONS 17
- USE 18
- CORRECT BODY POSTURE 18
- MAINTENANCE 18
- STORAGE 19
- IMPORTANT NOTICE 19
- DRAWING 20
- PARTS LIST 21
- ENVIRONMENT PROTECTION 25
- TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS..... 25


SevenSport s.r.o. reserves the right to make any changes and improvements to its product without prior notice. Visit our website www.insportline.eu where you will find the latest version of the manual.

SAFETY INSTRUCTIONS

- To ensure the best safety of the exerciser, regularly check it on damages and worn parts.
- If you pass on this exerciser to another person or if you allow another person to use it, make sure that that person is familiar with the content and instructions in these instructions.
- Only one person should use the exerciser at a time.
- Before the first use and regularly make sure that all screws, bolts and other joints are properly tightened and firmly seated.
- Before you start your work-out, remove all sharp-edged objects around the exerciser.
- Only use the exercise for your work-out if it works flawlessly.
- Any broken, worn or defective part must immediately be replaced and/or the exerciser must no longer be used until it has been properly maintained and repaired.
- Parents and other supervisory persons should be aware of their responsibility, due to situations which may arise for which the exerciser has not been designed and which may occur due to children's natural play instinct and interest in experimenting.
- If you do allow children to use this exerciser, be sure to take into consideration and assess their mental and physical condition and development, and above all their temperament. Children should use the exerciser only under adult supervision and be instructed on the correct and proper use of the exerciser. The exerciser is not a toy.
- Make sure there is sufficient free space around the exerciser when you set it up at least 0.6 m.
- To avoid possible accidents, do not allow children to approach the exerciser without supervision, since they may use it in a way for which it is not intended due to their natural play instinct and interest in experimenting.
- Please note that an improper and excessive work-out may be harmful to your health.
- Please note that levers and other adjustment mechanisms are not projecting into the area of movement during the work-out.
- When setting up the exerciser, please make sure that the exerciser is standing in a stable way and that any possible unevenness of the floor is evened out.
- Always wear appropriate clothing and shoes which are suitable for your work-out on the exerciser. The clothes must be designed in a way so that they will not get caught in any part of the exerciser during the work-out due to their form (for example, length). Be sure to wear appropriate shoes which are suitable for the work-out, firmly support the feet and which are provided with a non-slip sole.
- Be sure to consult a physician before you start any exercise program. He may give you proper hints and advice with respect to the individual intensity of stress for you as well as to your work-out and sensible eating habits.
- The indoor bike has no freewheel. The pedals will move if the flywheel is spinning.
- If you do not use the indoor bike, increase the resistance to the maximum to prevent the flywheel from moving.
- Assemble the exerciser as per assembly instructions and be sure to only use the structural parts provided with the exerciser and designed for it. Prior to the assembly, make sure the contents of the delivery are complete by referring to the parts list of the assembly and operating instructions.
- Be sure to set up the exerciser in a dry and even place and always protect it from humidity. If you wish to protect the place particularly against pressure points, contamination, etc., it is recommended to put a suitable, non-slip mat under the exerciser.



- The general rule is that exercisers and training devices are no toys. Therefore, they must only be used by properly informed or instructed persons.
- Stop your work-out immediately in case of dizziness, nausea, chest pain or any other physical symptoms. In case of doubt, consult your physician immediately.
- Children, disabled and handicapped persons should use the exercise only under supervision and in presence of another person who may give support and useful instructions.
- Be sure that your body parts and those of other persons are never close to any moving parts of the exerciser during its use.
- When adjusting the adjustable parts, make sure they are adjusted properly and note the marked, maximum adjusting position, for example of the saddle support, respectively.
- Do not work out immediately after meals!
- **Category:** SA for commercial use
- **Maximal weight limit:** 160 kg.

PRODUCT DESCRIPTION



1.	Smartphone holder	7.	Left pedal
2.	Console	8.	Seat
3.	Handles	9.	Seat position adjustment lever
4.	Left fan cover	10.	Rear frame
5.	Front stabilizer	11.	Right pedal
6.	Hand knob	12.	Rear stabilizer

FASTENERS


Pic.	No.	Name	Qty.
	84	Button Head Cap Screw, M6x12mm	9
	102	Button Head Cap Screw, M6x70mm	3
	114	Socket Head Cap Screw, M8x15mm	8
	115	Spring Washer, M8	8
	82	Flat Washer, M8	9
	92	Phillips Pan Head Self-Tapping Screw, ST4.2x6mm	1
	93	Wire Pin	2
	96	Phillips Pan Head Self-Tapping Screw, ST4.2x16mm	4
	81	Button Head Cap Screw, M8x75mm	1
	83	Nylon Nut, M8	1
	162	Socket Head Cap Screw, M8x12mm	1
	163	Arc Washer M8	1
	164	Socket Head Cap Screw, M5x8mm	1

ASSEMBLY

Step 1

Connect the front stabilizer (7) to the front frame (1) using 4x M8x15mm screws (114), 4x M8 spring washers (115) and 4x M8 washers (82).


Tighten all screws.



Step 2

Connect the rear stabilizer (8) to the rear frame (2) using 4x M8x15mm screws (114), 4x M8 spring washers (115) and 4x M8 washers (82).

Tighten all screws.



Step 3


Pull out and place the main frame (3) on the largest cardboard from the box. Place the main frame as shown.

The left fan cover (50) should face the box.

Do not place the frame on the floor, you may damage the fan covers (50).


Attach the front frame (1) to the main frame (3) using 3x M6x70mm screws (102) and 1x M6x12mm screw (84).

Attach the rear frame (2) to the main frame (3) using 8x M6x12mm screws (84).



Step 4

Fix the console cable (16) to the bracket (93) and the main frame (1) with 1x ST4.2x6mm screw (92).




Step 5

Press the lever (9) and slide the handlebar post (5) into the main frame (1). Secure the handlebar post (5) in the main frame (1) with the hand knob (160).

Loosen the hand knob (56) on the top of the handlebar post (5) and insert the handles (4). Secure with hand knob (56).

Attach the saddle (67) to the seat post (6) using the M8x12 mm screw (162) and the M8 curved washer (163).

Tighten all screws.



Step 6


Attach the console holder (55) and cable bracket (93) to the handles (4) with 4x ST4.2x16mm Screws (96). Attach the cable holder to the bottom side.

Attach the console (10) to the console holder (55) using 1x M8x75mm Screw (81), M8 Flat Washer (82) and M8 Nut (83).

Plug the cable (16) into the console (10a) as shown.


Then use the M5x8mm screw (164) to secure the handles (4).

Tighten all screws.




Step 7

Attach the left pedal (23) to the left crank (21) and the right pedal (24) to the right crank (22).



Step 8

Attach the bottle holder (149) to the main frame (3) using 2x M5x12mm screws (116).



CONTROL PANEL



INTRODUCTION

Turn on

Move the pedals to turn on the quick start program or press any button to enter standby mode

After first start you need to set DATE and TIME. Set the DATE and TIME with arrow buttons and confirm with ENTER.

Turn off

If the control panel is in standby mode or no activity is recorded for 20 seconds, it turns off.

If the interval program is running, the console will shut down after 2 min of inactivity.

In countdown programs, the console will shut down after 30 min of inactivity.

Battery replacement

The control panel is powered by 2x D batteries. The batteries are located on the back of the control panel.

If the batteries are not inserted, you can still exercise in the quick start program.

FUNCTION

PROG button

In standby mode, press the program selection button. You can set targets for distance, time and calories or you can choose an interval program for distance, time and calories.

Note: The default program is a quick start program.

DISPLAY button

In the exercise mode, hold the button, you will hear a beep and the display will show other data. Hold the button again, you will hear a 2x beep and the display will show the previous data.

By pressing the button while viewing the exercise summary or viewing the information stored in the memory, you switch between the two types of data.

STOP button

During program selection, the button serves as a return to the previous program. During the setting of the values, the button serves as a return to the previous value after confirmation.

During the exercise, press the button to stop the exercise. Calorie and watt values are reset to zero. Press the button again to view the exercise summary. Press the button a third time to return the control panel to standby mode.

If you want to save the exercise values (does not apply to the quick start program), press the button to save the values to memory.

Holding down the button resets all values and the control panel switches to standby mode.

Up button ▲

Press the button to increase the value. Hold the button to increase the value faster.

If you are viewing the data in the memory, the button serves as a navigation button.

Down button ▼

Press the button to decrease the value. Hold down the button to decrease the value faster.

If you are viewing the data in the memory, the button serves as a navigation button.

ENTER button

Press to confirm program selection or value setting.

Right button ►

If you are setting a program, press the button to move between the digits.

You try to view the data in the memory, by pressing the button you switch between individual cycles.

Left button ◀

If you are setting a program, press the button to move between the digits.

You try to view the data in the memory, by pressing the button you switch between individual cycles.

DISPLAY

Time and date

- Range: 0:00:00 – 17:59:59 (hours, minutes, seconds)
- Time is added in all cases, except if a time countdown is set.
- The maximum value in the quick program is 02:34:59, in all other programs the maximum value is 17:59:59. Once the value reaches its maximum, it will count again from 0:00:00.
- D, M, Y (day, month, year) are only displayed when the control panel is in standby or memory mode.
- To reset the time and date, hold the PROG and DISPLAY buttons simultaneously in standby mode.

RPM

- Displays the current revolution per minute during exercise
- Range: 0 - 199

TIME/1KM & AVE TIME/1KM & TIME & REST TIME

- Range: 00:00 – 99:59 (minutes:seconds)
- TIME/1km is the approximate time to cover 1km depending on RPM
- AVE TIME/1km is the approximate time to cover 1 km during the entire exercise
- TIME is the current time in the format 00:00 - 24:00 hours, displayed only if the console is in standby mode
- REST TIME is the rest time in the interval program, range: 00:10 – 00:30

Level

- Current exercise resistance
- Range: 1 – 32

Cycle

- Range for cycle: 0 – 35
- Only shown in the interval program. Displays the current interval.

Watts, ave watts

- Range: 0 – 999
- It will display the power in watts during the exercise
- Average power is the average power output during exercise

Pulse, drag

- Heart rate display: 40 -220 beats per minute during exercise
- You must be wearing a paired chest strap with a connection frequency of 5.3 kHz for display
- The stroke represents the cadence and resistance you feel during the stroke

Total meter, total meter/30 min

- Range: 0 – 99999 meters
- If the value exceeds the maximum limit, it is reset to zero and will count again from 0
- Total distance is added in all modes (except if distance countdown is set)
- Total distance/30min is an approximate calculation of how much distance you will cover in 30 minutes at the current cadence of strokes.

Calories, calories/hr

- Range: 0 – 9999
- If the value exceeds the maximum limit, it is reset to zero and will count again from 0
- Calories Burned/Hour approximate number of calories burned per hour with the current stroke cadence

Split time/500m, split calories

- Range: 00:00 – 99:59 (hours:minutes)
- Displays the average split time for 500m

Split xx

- Range: 0 – 35
- The split is displayed in the exercise summary or memory.
- If the value is 0, it means that no exercise split was performed.

Memory

- Range: 0 – 35
- Shows saved previous workouts.
- Numbering is 1 newest, 35 oldest. The oldest saved positions are replaced when the maximum value of 35 is reached.

PROGRAMS

- The control panel includes 8 programs: Quick start, Distance Countdown, Time Countdown, Calories Countdown, Time Interval, Distance Interval, Calorie Interval and memory.
- By pressing PROG you can switch between the programs in the following order: Quick start, Distance Countdown, Time Countdown, Calories Countdown, Time Interval, Distance Interval, Calorie Interval and memory.
- To change the displayed data during training, press the DISPLAY button. The displayed values also change automatically every 5 seconds.
- Press STOP once to stop counting, Calories and Watts will reset to zero. Press the STOP button again to view the exercise summary. If you press the STOP button in the exercise summary, you will save the workout to memory.

Note: A quick program workout cannot be saved to memory.

Quick start program

- To start the program, just you start pedaling. All values will start to add up. The program starts the moment you start pedaling.
- Press STOP to display the exercise summary, but the data cannot be saved to memory.

Time countdown

- During the exercise, the time will be subtracted from the set value.
- Range: 00:00:20 – 09:59:59 (hours:minutes:seconds)

After setting, the program starts the moment you start pedaling. Once you've reached your target, you'll see a workout summary. If you press STOP while the summary is displayed, the data is stored in memory and the control panel goes into standby mode

Distance countdown

- During the exercise, the distance will be subtracted from the set value.
- Range: 1 – 500 km/mil
- After setting, the program starts the moment you start pedaling. Once you've reached your target, you'll see a workout summary. If you press STOP while the summary is displayed, the data is stored in memory and the control panel goes into standby mode.

Calories countdown

- During exercise, calories will be subtracted from the set value.
- Range: 1 – 5000 cal
- After setting, the program starts the moment you start pedaling. Once you've reached your target, you'll see a workout summary. If you press STOP while the summary is displayed, the data is stored in memory and the control panel goes into standby mode.

Time interval

- The time interval setting consists of training time (time) and rest (rest).
- First, you need to set the time of each training interval. After setting all training intervals, press ENTER to set rest intervals.

- Training range: 00:00:20 – 09:59:59 (hours:minutes:seconds)
- Rest range: 00:10 – 30:00 (minutes:seconds)
- Number of intervals: 35

Distance interval

- The distance interval setting consists of total km and rest time.
- First, you need to set the distance of each training interval. After setting all training intervals, press ENTER to set rest intervals.
- Training range: 1 – 50 km/mil
- Rest range: 00:10 – 30:00 (minutes:seconds)
- Number of intervals: 35

Calories interval

- The calorie burn interval setting consists of calories burned (calories) and rest (rest).
- First, you need to set the calorie value of each training interval. After setting all training intervals, press ENTER to set rest intervals.
- Training range: 10 – 5000 cal
- Rest range: 00:10 – 30:00 (minutes:seconds)
- Number of intervals: 35

Memory mode

- Use the PROG button to select MEMORY. Press ENTER to enter the memory. You can switch between individual workouts using the up and down keys.
- Press ENTER to enter the selected workout. Use the right and left arrows to scroll through individual training data.
- Only training programs can be stored in the memory, the quick exercise program cannot be stored.
- The control panel records up to 88 intervals. Up to 35 exercises can be stored in the memory.
- The console automatically deletes the oldest data when the limit is exceeded.
- A lower marker in the memory shows more recent exercises.
- You can change the displayed information with the DISPLAY button.
- The SPLIT trial shows “00”, this means that this is the overall average of the exercise without intervals.

Interval table

Time Countdown	
Rule	Split:
10 hrs > time > 5 hrs	30 min
5 hrs >= time > 200min	15 min
200 min >= time > 100min	10 min
100 min >= time > 60min	5 min
60 min >= time > 20min	3 min
20 min >= time > 5min	1 min
5 min >= time > 1min	30 sec
1 min >= time	20 sec

Calories Countdown	
Rule	Split:
5000 >= calories > 4000	250 kal
4000 >= calories > 3000	200 kal
3000 >= calories > 2000	150 kal
2000 >= calories > 1000	100 kal
1000 >= calories > 500	50 kal
500 >= calories > 100	20 kal
100 >= calories	10 kal

Interval programs	
Rule	Split:
1 cycle = 1 interval	Up to 35

Distance countdown	
Rule	Split:
500 >= distance > 250	20 km
250 >= distance > 100	10 km
100 >= distance > 50	5 km
50 >= distance > 20	2 km
20 >= distance	1 km

Note: if the value is not divisible by the splits, the last part will not be shown if you are looking at exercise intervals, but will be shown to the total number of intervals.

Example: if you reach distance 1200m, the total number of intervals will be displayed for 1200m, but in the details you will only see the interval for 1000m, the last 200m interval will not be displayed. The same applies if you do not complete the training.

BLUETOOTH

Turn on control Panel and turn on Bluetooth on your smart device.

Connection is possible using the Kinomap and D-Fit applications.


The connection takes place via the FTMS protocol.

"bt" is displayed in the lower left corner of the display if the control panel is connected. Once the control panel is connected, the control panel buttons are not active.

Your smart device must have external Bluetooth device connectivity enabled.


RESISTANCE ADJUSTMENT

The level of resistance is shown on the left side of the fan cover (50). Use the indicator (49) to set the required resistance. Resistance can be set from 1 (lowest) to 32 (highest)



HANDLES AND SEAT POSITIONS

- You can adjust the height of the seat (67) by pressing the lever (9).
- You adjust the height of the handles (4) by loosening the hand knob (160) and pressing the lever (9) under the handles.
- Adjust the position of the handles (4) by loosening the hand knob (56).



USE

Exercise on the indoor bike is based on very simple movements, but you will surely fall in love with them. Thanks to simplicity of the exercise on the indoor bike it can be done by elderly people. Prior to exercise, it is necessary to adjust the height of the saddle. It is important that you sit comfortably. The bicycle saddle must be set so that you can hold the ergonomically shaped handles when sitting. You should not have fully extended hands. You can damage your muscles.

To ensure a comfortable and comfortable exercise, put your feet on the pedal. Nowadays, all modern pedals are equipped with straps for fastening and stabilizing of the foot. It is important for your foot to be firmly and safely positioned during exercise.

The basis of exercising on a bicycle is that the legs are moving on a specific elliptical path. This movement is very similar to cycling. When doing exercise on a bicycle, you just sit on the saddle with the right height, keep your feet firmly in the pedals, hold the ergonomically shaped handles and exercise.

It is advisable at the beginning to choose a lower load. If you exercise at regular intervals on an indoor bike, you can gradually increase the load. You can increase the load gradually over a week or two weeks. Selecting a high load during the start of training can lead to rapid fatigue and muscle damage.

When exercising, it's important to choose the right load and the right tempo. Try to keep it throughout the exercise. It is not recommended to choose a high pace right from the start. Increase tempo after about a week of regular exercise. The high pace is not equal to the faster burning of calories. Correct calorie burning is reflected in an appropriate and regular exercise. At the beginning of the exercise, the number of burned calories may seem low, but regular and appropriate exercise is the key to achieving the best results.

Exercise on the indoor bike also leads to the formation of muscles. It is mainly used to strengthen the thigh and calf muscles. While exercising on a bicycle, you also move your buttocks.

If you want to exercise right, you should not forget to breathe properly. Proper and regular breathing is recommended in any exercise. It is important to keep regular deep inhales and exhales. Regular and proper breathing during exercises on the indoor bike involves intense exercise of the abdominal muscles. It is advisable to practice 30-35 after consuming food. Failure to do so may result in less calories burned, and in older age even lead to digestive problems.

For best results, you should also consider your diet. It is recommended to start a day of eating sweet food and pastries or muesli with milk. For lunch is recommended to eat a caloric richer meal. Do not forget about the soup. In the evening, light meals are recommended. If you want to improve your health, it's not just a regular exercise but a whole diet.

Bicycle exercise is an effective exercise for all busy people. Exercise on the indoor bike is effective in strengthening muscles, especially thighs, calves and buttocks. Regular exercise can lead to a slimmer figure. Exercise is recommended not only as a winter training for cyclists but also for people who want to burn excess calories. Regular breathing, regular exercise, reasonable tempo, and balanced diet can lead to your desired results.

CORRECT BODY POSTURE

When training, keep your body upright, or you can learn your hand on your forearms. During pedaling, you should not have your legs fully extended. Your knees should be slightly bent when fully pressing down the pedal. Keep your head straight with your spine to minimize the pain of the cervical muscles and upper back muscles. Always exercise fluently and rhythmically.

MAINTENANCE

- When assembling, tighten all screws and adjust the bike to the horizontal position.
- Check the screws after 10 hours of use.
- Wipe the sweat after the exercise. Clean the device with a cloth.
- When noise is increased, it is necessary to check that all joints are tightened properly.

- Place the product in a clean, ventilated and dry room.
- Do not expose the device to direct sunlight.


STORAGE

Keep the indoor bike in a clean and dry environment. Make sure the power switch is turned off and the indoor bike is not plugged into the power socket.

IMPORTANT NOTICE

- This indoor bike comes with standard safety regulations and is suitable for commercial use.. We are not responsible for any injury caused by improper and forbidden use of the machine.
- Consult your doctor before starting training on the indoor bike. Your doctor should evaluate whether you are physically fit to use the machine and how much effort you are able to undergo. Incorrect exercise or switching of the body can harm your health.
- Carefully read the following tips and exercises. If you experience pain, nausea, breathing, or other health problems during exercise, immediately stop the exercise. If the pain persists, contact your doctor immediately.
- This indoor bike is not suitable as a professional or medical purpose. It can also not be used for healing purposes.
- The heart rate monitor is not a medical device. It provides only approximate information about your average heart rate, and any suggested pulse rate is not medically binding. Accumulated data may not always be accurate regarding uncontrollable human and environmental factors.

DRAWING



PARTS LIST

No.	Name	Qty.
1	Front Post Frame	1
2	Rear Post Frame	1
3	Main Frame	1
4	Handlebar	1
5	Handlebar Adjustment Post	1
6	Seat Bracket	1
7	Front Stabilizer Tube	1
8	Rear Stabilizer Tube	1
9	Adjustment Lever	2
10	Monitor	1
11	Adaptor Board	1
12	VR	1
13	Generator	1
14	VR Wire	1
15	Generator Wire	1
16	Monitor Wire	1
17	Large Single Belt Pulley	1
18	Pulley Bearing	1
19	Bearing Holder 6004	2
20	Ball Bearing 6004ZZ	2
21	Left Crank	1
22	Right Crank	1
23	Left Pedal	1
24	Right Pedal	1
25	Double Belt Pulley	1
26	Ball Bearing 6000ZZ	2
27	Pulley Spacer $\Phi 14 \times \Phi 10 \times 39.5 \text{mm}$	1
28	Fan Axle	1
29	Single Belt Pulley	1
30	Rubber Bushing 6001	1
31	Rubber Bushing 6001	1
32	Ball Bearing 6001ZZ	7
33	Rubber Bushing 6003	1
34	Ball Bearing 6003ZZ	1
35	Bearing Spacer $\Phi 40.2 \times \Phi 38 \times 54.2 \text{mm}$	1
36	One-way Bearing	1

37	Ball earing 6201RS	3
38	C Ring $\Phi 32$	1
39	Magnet	1
40	Drive Belt 380J4	1
41	Drive Belt 400J11	1
42	Long Pinch Roller $\Phi 38 \times \Phi 24 \times 34.5 \text{mm}$	2
43	Short Pinch Roller $\Phi 38 \times \Phi 26.4 \times 14 \text{mm}$	2
44	Flywheel	1
45	Bottom Cover	1
46	Stainless Steel Upper Cover	1
47	Stainless Steel Mesh	1
48	Large Pulley Spacer $\Phi 14 \times \Phi 10 \times \Phi 6 \times 8 \text{mm}$	2
49	Damper	1
50	Left Fan Shroud	1
51	Right Fan Shroud	1
53	Steel Plate	2
54	Axle Cover	1
55	Monitor Holder	1
56	Star Nut	1
57	Handlebar Post Bushing	2
58	Post Frame Pushing A	2
59	Post Frame Pushing B	2
60	Protection Cover for Seat Post Lever	2
62	Generator Base	1
63	Generator Cover	1
64	Protection Cover	1
65	Transport Wheel	2
66	Stabilizer Feet Pad	4
67	Seat Cushion	1
68	Left Pinch Roller Bracket	2
69	Right Pinch Roller Bracket	2
70	Large Spacer for Long Pinch Roller $\Phi 18 \times \Phi 12 \times 29.5 \text{mm}$	1
71	Small Spacer for Long Pinch Roller $\Phi 10 \times \Phi 6. \times 9.5 \text{mm}$	1
72	Large Spacer for Short Pinch Roller $\Phi 18 \times \Phi 12 \times 8 \text{mm}$	1
73	Small Spacer for Short Pinch Roller $\Phi 10 \times \Phi 6 \times 31 \text{mm}$	1
77	EVA Pad for Smartphone Holder Base	1
79	Left Torsion Spring	1
80	Right Torsion Spring	2

81	Button Head Cap Screw, M8x75mm	3
82	Flat Washer, M8	13
83	Nylon Nut, M8	6
84	Button Head Cap Screw, M6x12mm	35
85	Inner Star Washer, M6	5
86	Button Head Cap Screw, M6x43mm	3
87	Socket Head Cap Screw, M5x92mm	4
88	Socket Nut, M5	4
89	Socket Head Cap Screw, M4x12mm	3
90	Carriage Bolt, M8x75mm	1
91	Nylon Nut, M10	2
92	Phillips Pan Head Self-Tapping Screw, ST4.2x6mm	7
93	Wire Pin	2
94	Phillips Pan Head Screw, M4x45mm	1
95	Socket Nut, M4	1
96	Phillips Pan Head Self-Tapping Screw, ST4.2x16mm	9
97	Socket Head Cap Screw, M8x25mm	2
98	Socket Head Cap Screw, M8x35mm	2
99	Socket Head Cap Screw, M6x20mm	4
100	Spring Washer, M6	4
101	Socket Head Cap Screw, M6x15mm	12
102	Button Head Cap Screw, M6x70mm	3
103	Button Head Cap Screw, M6x75mm	2
104	Flat Washer, M6	2
105	Nylon Nut, M6	14
106	Button Head Cap Screw, M6x22mm	2
107	Hex Head Cap Screw, M6x12mm	2
108	Phillips Rounded Washer Head Screw, M4x10mm	7
111	Phillips Pan Head Self-Tapping Screw, ST3.0x20mm	2
112	Phillips Pan Head Self-Tapping Screw, ST3.0x6mm	6
113	Button Head Cap Screw, M8x40mm	2
114	Socket Head Cap Screw, M8x15mm	8
115	Spring Washer, M8	8
116	Phillips Pan Head Screw, M5x12mm	6
117	Phillips Pan Head Self-Tapping Screw, ST4.2x10mm	6
119	Bearing Spacer $\Phi 16 \times \Phi 8.1 \times 20.5$ mm	2
120	Allen Wrench, 4mm	1
121	Allen Wrench, 6mm	1

122	Open End Wrench, 13mm/ 15mm/ 17mm	1
123	VR Holder	1
124	Pin, M6x80mm	2
125	Post, M6x64mm	4
126	Magnet Bracket	2
127	Stainless Steel Spacer $\Phi 10 \times \Phi 6 \times 25 \text{mm}$	6
128	Aluminum Plate	1
129	Round Magnet	6
130	Back Handlebar Holder	1
131	Front Handlebar Holder	1
132	Horizontal Handlebar Adjustment Post	1
133	Seat Adjustment Post	1
134	Indicator	1
135	Plastic Mesh	1
136	Magnet Bracket Base	1
137	Smartphone Holder	1
138	Bungee Cord	1
139	EVA Pad for Smartphone Holder	1
141	Shoulder Washer	3
142	Spring	2
143	Handlebar Pin	1
145	Hex Head Cap Screw, M6x20mm	6
146	Hex Head Cap Screw, M6x40mm	6
147	Phillips Head Screw, M6x10mm	4
148	Phillips Flat Head Screw, ST4.2x16mm	6
149	Water Bottle Holder	1
150	Nylon Nut M8	2
151	Socket Head Cap Screw, M6x25mm	4
153	Special-shaped EVA Pad (Left)	2
154	Special-shaped EVA Pad (Right)	2
155	Wafer	1
156	Phillips Pan Head Screw, M5x10mm	1
157	Phillips Pan Head Screw, M5x30mm	1
158	90°V fore-set	1
159	Inner& Outer thread Nut Bushing	1
160	Plum-shaped Knob	1
161	Sleeve	2
162	Socket Head Cap Screw, M8x12mm	1

163	Arc Washer M8	1
164	Socket Head Cap Screw, M5x8mm	1
165	Blocked Sweating Block	1

ENVIRONMENT PROTECTION

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyard.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Strakonická street 1151/2c, Prague 150 00, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

Batteries

6-month battery warranty – we guarantee that battery's nominal capacity does not fall below 70% of its total capacity within 6 months of the product's sale.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance

- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

CZ **SEVEN SPORT s.r.o.**

Registered Office: Strakonická 1151/2c, Praha 5, 150 00, ČR

Headquarters: Dělnická 957, Vítkov, 749 01
Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264
VAT ID: CZ26847264

Phone: +420 556 300 970
E-mail: eshop@insportline.cz
reklamace@insportline.cz
servis@insportline.cz

Web: www.inSPORTline.cz

SK **inSPORTline s.r.o.**

Headquarters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 36311723
VAT ID: SK2020177082

About shipping



Phone: +421(0)326 526 701
E-mail: objednavky@insportline.sk
reklamacie@insportline.sk
servis@insportline.sk
Web: www.inSPORTline.sk