




# ***CHEST PRESS***

## **USER MANUAL**



### **NOTE!**

Read all instructions carefully before using this product. Retain this owner's manual for future reference. The specifications of this product may vary and are subject to change without further notice.



GYMSTICK.COM

# BEFORE YOU BEGIN

Thank you for choosing Gymstick training equipment. We take great pride in producing this high-quality product and hope it will make you feel better and enjoy life to the fullest. Please read this manual in its entirety before beginning to use this product.



## IMPORTANT

Read all instructions carefully before using this product.  
 Retain this owner's manual for future reference.



## WARNING

Read and follow all safety instructions carefully.  
 Failure to follow safety instructions could result in serious injury.

|                       |    |
|-----------------------|----|
| BEFORE YOU BEGIN      | 2  |
| SAFETY INSTRUCTIONS   | 3  |
| PARTS LIST            | 4  |
| ASSEMBLY INSTRUCTIONS | 5  |
| IMPLIED WARRANTY      | 13 |

# SAFETY INSTRUCTIONS

Basic precautions should always be followed when using this machine. In order to ensure safe Read and follow all safety instructions included in this user manual. Failure to do so could result in serious injury.



## WARNING

Before using this product, consult your physician first. This is especially important for individuals over the age of 35 or persons with pre-existing health problems.

- ▲ This product is not a toy. Keep children and pets away from the machine at all times. Do not leave unattended children in the same room with the machine.
- ▲ Handicapped or disabled persons should not use the machine without the presence of a qualified health care professional or physician.
- ▲ If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms, stop the workout at once. Consult a physician immediately.
- ▲ Before beginning training, remove all objects within a radius of 2 meters from the machine. Do not place any sharp objects around the machine.
- ▲ Position the machine on a clear, level surface away from water and moisture. It is suggested to place a mat under the unit to help keep the machine stable and to protect the floor.
- ▲ Only use the machine for its intended purpose as described in this manual. Do not use any other accessories than the ones recommended by the manufacturer.
- ▲ Assemble the machine exactly as in the description in this instruction manual.
- ▲ Check all bolts and other connections before using the machine for the first time and ensure that the machine is in good and safe condition.
- ▲ Hold a routine inspection of the equipment. Pay special attention to components which are the most susceptible for wear and tear. Any defective components should be replaced immediately before using the machine.
- ▲ Never operate the machine if it is not functioning properly.
- ▲ This machine can be used for only one person's training at a time.
- ▲ Do not use abrasive cleaning articles to clean the machine. Wipe drops of sweat from the machine immediately after finishing training.
- ▲ Always wear appropriate workout clothing when exercising. Running or aerobic shoes are also required.
- ▲ Before exercising, always warm-up your body thoroughly by dynamic stretching our a warm-up routine.
- ▲ This machine is intended for commercial and professional use.
- ▲ This machine must be assembled by adults.
- ▲ It is the responsibility of the owner to ensure that all users are properly informed as how to use this product safely.
- ▲ Maximum user weight: 150 kg.


## PARTS LIST

| PART | DESCRIPTION            | QTY |
|------|------------------------|-----|
| 1    | Weight Stack Frame     | 1   |
| 2    | Bottom Connection Tube | 1   |
| 3    | L Support Tube         | 1   |
| 4    | Seat Frame             | 1   |
| 5    | L Connection Tube      | 1   |
| 6    | U Plate                | 2   |
| 7    | Rod Retainer           | 2   |
| 8    | Retaining Ring D25     | 4   |
| 9    | Guide Rod              | 2   |
| 10   | Weight Pin             | 1   |
| 11   | Top Weight Plate       | 1   |
| *    |                        |     |
| 13   | Weight Plate 15 LBS    | 14  |
| 14   | Weight Label           | 1   |
| 15   | Rubber Ring            | 2   |
| 16   | Back Rest Frame        | 1   |
| 17   | Swinging Arm           | 1   |
| 18   | Seat                   | 1   |
| 19   | Pulley D114            | 6   |
| 20   | Handle                 | 1   |
| 21   | Cable 4336mm           | 1   |
| 22   | Upper U Plate          | 2   |
| 23   | Hole Cap D25           | 9   |
| 24   | Head Pad               | 1   |
| 25   | Back Pad               | 1   |
| 26   | Seat Pad               | 1   |
| 27   | Back Lower Shield      | 1   |
| 28   | Front Lower Shield 1   | 1   |
| 29   | Front Lower Shield 2   | 1   |
| 30   | Front Upper Shield     | 1   |
| 31   | Back Upper Shield      | 1   |
| 32   | Pop Pin                | 1   |
| 33   | FE Tube Cap 50×100     | 1   |
| 34   | Panel Clip             | 20  |
| 35   | Plate 8×50×100         | 1   |
| 36   | L Rubber Foot          | 4   |
| 37   | Rubber Pad 50×100      | 2   |
| 38   | Upper Lateral Tube     | 1   |
| 39   | Pull Pin               | 1   |
| 40   | Spring                 | 1   |
| 41   | Knob                   | 1   |
| 42   | Outer Tube Bushing     | 3   |
| 43   | Inner Tube Bushing     | 1   |
| 44   | FE Tube Cap 40 × 80    | 3   |
| 45   | Shaft D25 × 380        | 1   |
| 46   | Bearing 6205           | 2   |
| 47   | Joint Bearing          | 1   |

[illegible]

## ASSEMBLY INSTRUCTIONS

## PREASSEMBLED




# ASSEMBLY INSTRUCTIONS

## STEP 1

### INFORMATION:

We recommend you have someone assist you in lifting and assembling your gym.

Follow these steps carefully and it will make it easier to assemble your gym.




50%



# ASSEMBLY INSTRUCTIONS

## STEP 2




50%



**NOTE!** Please clean the weight plates before fixing the weight stickers, and avoid touching the adhesive of the sticker. If the movement of the weight stack is not smooth during workout, please lubricate the guide rods.


ASSEMBLY INSTRUCTIONS

STEP 3




ASSEMBLY INSTRUCTIONS

STEP 4




ASSEMBLY INSTRUCTIONS

STEP 5




ASSEMBLY INSTRUCTIONS

STEP 6



# ASSEMBLY INSTRUCTIONS

## STEP 7



**NOTE!** After assembling the equipment, please check and tighten all the fasteners including the screws on the handle.

100%

# IMPLIED WARRANTY

The importer of this product assures that this device is manufactured with high quality materials. The implied warranty is valid for 1 (one) year, beginning from the date of purchase. The guarantee is valid for professional use.

## The warranty applies to the following parts:

- Frame
- All parts included in the original delivery

## The warranty does not apply to the following parts:

- Wearing parts (e.g. cushions, bearings, cables, pulleys, etc.)

## The warranty does not cover:

- Incorrect installation
- Damage caused externally
- Use of unauthorised service partners
- Failure to carry out regular maintenance and servicing
- Improper use and handling of the equipment
- Improper storage of the equipment
- Non-compliance of the operating instructions

## MANUFACTURED FOR

Gymstick International Oy  
Ratavartijankatu 11  
15170 Lahti, FINLAND

## DISCLAIMER

The manufacturer and its associates and partners have no liability, obligation or responsibility to any person or entity for any loss, damages or adverse consequence alleges to have happened directly or indirectly as a consequent of this product.



Products marked with these symbols must be disposed of separately from your household waste, as they contain valuable materials which can be recycled. Proper disposal protects the environment and human health. Your local authority or retailer can provide more information on the matter.

